



4113 (00-711)

Mini basket 15 x 11 x 6cm



4112

Small basket 18.5 x 14.5 x 7cm



4226 (7005)

Basket 19 x 15 x 6.5cm



4250 (7000)

Basket 40.5 x 30.5 x 12cm



4317 (30-710)

Basket 40 x 29.5 x 10cm



4081 (32-710)

Basket 40 x 29 x 11.5cm



2393

Basket 32 x 26 x 5cm



2432

Basket 33.5 x 23 x 13cm



2403

Basket 35 x 24.5 x 10cm




3434

Basket 57 x 35.5 x 33cm



2461

Stand with baskets 20 x 12 x 16cm



4166

Small heart basket 18.5 x 16 x 4.5cm



4167

Medium heart basket 23 x 19.5 x 5cm



4168

Large heart basket 29 x 24.5 x 7cm



4318

(72-729)

Heart basket 31 x 27 x 19cm



4319 (03-729)

Heart basket w. handle 16.5 x 14.5 x 10.5cm



4320

(02-729)

Heart basket w. handle 32.5 x 27 x 20cm



4322

(10-730)

Round basket w. handle Ø 16.5 x 13cm



4321

(67-710)

Rect. basket w. handle 33.5 x 25.5 x 21cm



2810

Flower basket w. handle 24.5 x 14.5 x 20cm



2843

Flower basket w. handle 26 x 19 x 12cm




2594

Basket with handle Ø 13 x 25cm



3027

Flower basket w. handle 40 x 21.7 x 21cm



2830

Fruit picking basket w. handle 38 x 15.5 x 6cm



3028

Basket w. handles 17.5 x 35 x 38cm



3030

Basket w. handles 13.3 x 11 x 9.7cm



3029

Basket w. handles 17.5 x 11 x 7.5cm