



3790

Micro tray w. lid Ø 22 x 4.5cm



4276 (9260)

Round micro lunch box w. lid 25 x 23 x 5cm



4289 (10-339)

Microwave box w. sections w. lid Ø 25 x 5cm



4169 (70-319)

Round micro lunch box w. lid Ø 19.5 x 5cm



4170 (80-319)

Rectangular micro lunch box 20 x 13.5 x 5cm



1825

Coaster for soda bottle Ø 12 x 9cm



4182 (93-319)

Cover for micro oven Ø 26 x 7cm



4222 (9250)

Cover for micro Ø 26 x 6.5cm



3159

Coaster for soda bottle Ø 14 x 8.5cm



3814

Grater w. bowl 23.5 x 19 x 8cm



0313

Salt box for wall 16 x 14 x 9cm



4295 (00-121)

Juicedispenser w. lid 11.5 x 8 x 19cm



1024

Glass holder Ø 6.5 x 7.5cm



0021

Glass holder 8.5 x 8.5 x 11.5cm



1357

Glass holder 6.5 x 4/10cm



1471

Tea strainer Ø 7 x 10.5cm



2391

Tea bag holder 11 x 7 x 1.5cm




2399

Spaghetti spoon 24 x 4.5 x 1cm



3813

Paper holder 27.5 x 11 x 8cm



1780

Cover for sink drainer pipe Ø 8 x 1.5cm



3448

baby bottle warm jug Ø 7 x 8cm



4086 (00-268)

Ice-cream spoon 27.5 x 5.5 x 5cm



1164

Bag opener 7 x 8 x 3.5cm