



1491

Egg holder 14 x 8cm



2314

Egg cup Ø 4.5 x 4.5cm



2316

Egg cup Ø 5 x 4.5cm



4026

Egg holder Ø 5.5 x 3.3cm



0183

Egg cup Ø 6 x 3cm



0182

Egg cup Ø 6 x 3cm



2596

Egg holder Ø 8.5 x 4.5cm



2398

Egg cup 9.5 x 9.5 x 2.8cm



3863

Egg cup Ø 10 x 3.5cm



0260

Egg cup Ø 10 x 3cm



1313

Egg holder Ø 11 x 2.5cm



3486

Egg holder 11 x 8.5 x 3cm



3109

Egg cup 11 x 8.5 x 3.5cm



1730

Egg cup 11 x 11 x 3cm



3147

Egg cups 11.9 x 8.9 x 3.25cm



1122

Egg cup 12 x 8.5 x 2.5cm




0102

Egg cup 14 x 8 x 2.5cm




0483

Oval egg holder 14 x 8 x 2.5cm



1801

Egg picker Ø 4 x 5.5cm



3946

6 Eggs holder 19.5 x 14 x 8cm