



0306

Cup w. lid for sweets Ø 5,5 x 7cm



0305

Sweet box 6,5 x 6,5 x 7cm



0307

Round sweet basket Ø 8 x 3,5cm



0307A

Rectangular sweet basket 8x 8 x 3,5cm



0297

Oval plate for sweet 10,7 x 8,5 x 1,0cm



0308

Round sweet basket w. lid Ø 9 x 3cm



3716

Sweet basket w. lid Ø 8 x 3cm



3076

Sweet box w. lid Ø 8,8 x 2cm



2607

Round box w. lid Ø 10 x 5cm



0309

Round sweet box w. lid Ø 8 x 2,5cm



0059

Sweet box w. lid 9 x 3,5 x 0,7cm



3344

Round box w. lid Ø 13,5 x 7,5cm



0385

Sugar dish w. lid Ø 8 x 6cm



3465

Sweet box w. lid Ø 8,5 x 8cm



1912

Sugar bowl w. lid Ø 8 x 10cm



3112

Salt box w. lid 12 x 13 x 12,7 cm



0078

Salt container for wall w. lid 17cm



1713

Sugar pourer Ø 7 x 15cm



1832

Salt shaker Ø 3,5 x 6cm



0458

Salt shaker Ø 3,5 x 7,5cm



1833

Salt shaker Ø 3,5 x 12cm



3437

Salt shaker 4 x 4 x 6cm



1765

Napkin ring Ø 4,5 x 4,5cm



2181

Salt shaker Ø 4,5 x 8cm



2054

Napkin ring Ø 5 x 4,5cm



0262

Salt shaker Ø 5 x 8cm



1818

Salt & pepper shakers Ø 6 x 16cm



2357

Salt & pepper in a basket 12 x 4,5 x 10cm



3226

Salt & pepper set 16 x 9 x 9cm



1073

Cruet set 10 x 5 x 3 cm



1858

2 sugar bowls w. lid Ø 14 x 5 cm



1127

Sugar bowl w. lid Ø 10 x 4,5 cm