



3960

Ice cube tray 26 x 5 x 4cm



2746

Ice cube tray 25.5 x 9 x 3cm



0201

Ice cube tray 25.5 x 9 x 2cm



2460

Butter dish 12.5 x 10.5 x 6cm



2168

Butter dish 14 x 5 x 4cm



3898

Cheese box w. lid 14 x 10 x 6 cm



2573

Ice cube tray (12) 29 x 11.5 x 6cm



3906

Ice cube tray 22.5 x 10 x 2.5cm



1954

Ice cube tray 23 x 9.5 x 3cm



3079

Butter dish 15 x 8.5 x 3.9cm



1269

Butter dish 15 x 9 x 4cm



0452

Butter dish 15 x 10 x 7 cm



1168

Ice cube tray 11 x 24cm



2294

Ice cube tray 25.5 x 11 x 3cm



3905

Ice cube tray 29 x 8.3 x 4.5cm



4249 (1610)

Butter dish 15.5 x 11.5 x 8cm




3162

Butter dish 16 x 9 x 5cm



2436

Butter dish 18 x 9 x 7.5 cm



3304

Ice balls tray (00-215) 21 x 6.5 x 2.5cm



0146

Ice cube tray 22 x 7 x 4cm



0373

Ice cube tray 22 x 8.5 x 2cm



2352

Butter dish 18 x 11 x 5.5cm



0984

Butter dish 18.5 x 10 x 6cm



2546

Butter dish 19 x 9 x 5 cm



0163

Ice bucket w. handle Ø 12 x 12.5cm



0173

Ice bucket w. handle Ø 12 x 13cm



0166

Ice bucket Ø 18.5 x 13.5cm



0048

Butter dish 19 x 9 x 7cm



2552

Cheese box w. lid 19.5 x 13.5 x 4cm



3129

Butter dish 20.5 x 10.5 x 5 cm



1157

Ice bucket w. lid Ø 17.5 x 20.5cm



3230

Ice bucket w. lid + handle Ø 19.5 x 21.5cm



1908

Dish w. cover 21 x 20 x 4.5cm